Install Telephone Set TA-312/PT
113-600-1012

Conditions: Given telephone set TA-312/PT; battery BA-30 or BA-3030, two each; tool equipment TE-33; installed telephone cable WD-1( )/TT; tags; grease pencil; Technical Manual (TM) 11-5805-201-12, and Training Circular (TC) 24-20.

Standards: The standards are met when the telephone set is installed and communications is established.

Performance Steps
1. Install the TA-312/PT on a desk, pole, or tree.
2. Set selector switch for proper service.
3. Connect telephone cable to the TA-312/PT.
4. Install power source.
5. Connect external headset when required.
6. Install/remove deicing screen when required.
7. Establish communications.

Evaluation Preparation: Setup: Ensure the telephone cable is laid. Brief soldier: Tell the soldier he must complete an outgoing call.

Performance Measures GO NO GO
(Refer to TM 11-5805-201-12 for performance measures (PMs) 1 through 7.)
1. Install the TA-312/PT on a desk, pole, or tree. —— ——
2. Set selector switch for proper service. —— ——
3. Connect telephone cable to the TA-312/PT. —— ——
4. Install power source. —— ——
a. Connect external batteries when required.
b. Install batteries in telephone set.
NOTE: PMs 4a and 5 may be used if the telephone operator must have his hand free during operation.
5. Connect external headset, when required. —— ——
6. Install/remove deicing screen when required. —— ——
7. Establish communications. —— ——

Evaluation Guidance: Score the soldier a GO if all PMs are passed. Score the soldier a NO-GO if communications is not established. If the soldier fails any PM, show what was done wrong and how to do it correctly. Have the soldier perform the PMs until they are done correctly.

References

Required	**Related**
TC 24-20	DVC 11-03
TM 11-5805-201-12	SS0411